



Installation Instructions



PRODUCT: JK/JL Sway Bar Link Extensions

REV: D | 08-04-2022 | II-7015

**READ INSTRUCTIONS IN FULL BEFORE INSTALLATION.
QUESTIONS? CALL 916-631-8071 M-F 7:00 AM – 5:00 PM PST**

The MetalCloak experience includes the ease of installation of our products. We design for most contingencies, but installation may be different based on different Jeep condition, configuration and/or year.

We are continually trying to improve our products and instructions – please help us by providing feedback and pictures if you find any part of the instructions that do not match your particular Jeep or are not easily understandable.

If you have any difficulties at all, please give us a call. Thank you and enjoy your MetalCloak Products!

IMPORTANT NOTE: We use Stainless Steel Hardware where possible. Therefore, a tube of Silver Anti-seize is provided and should be used on all bolts—only a small amount is needed.

WARRANTY INFORMATION: This article is sold without warranty expressed or implied. No warranty or representation is made as to this products ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED and/or MAINTAINED. THE USER ASSUMES ALL RISK. By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these MetalCloak products from Armored Works, LLC, its affiliates and distributors and agents as is and with all faults. The entire risk as to the quality and performance of these MetalCloak products is with the purchaser. Working on your vehicle can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or safety critical work to a skilled mechanic. We take no responsibility for the incorrect use and/or installation of MetalCloak products.

Section 1: Tools & Notes on Installation

Tools Required: This list is the recommended tools for ease of installation. Other versions of the same tool can be used. For example, Allen Wrenches instead of Allen Drive Sockets.



Socket & Ratchet Wrench

Torque Wrench



18mm Box Wrench (x2)
19mm Box Wrench

Red Loctite



HOW TO USE THIS GUIDE: The installation guide contains ALL steps for installation. Please read and follow the instructions in order of each page from top to bottom, and left to right.

Jeep Model: Instructions may apply to multiple Jeep models, but are labeled separately where appropriate (i.e. TJ vs. LJ).

Options: Because of the number of component options we offer, these instructions may contain steps that will not match your particular configuration. You can skip these steps.

Images: Pictures are provided and parts are labeled throughout the instructions. Each text box contains guidance based on the pictures next to it. The text will refer to alphabetical labels (A, B, etc) found in the images.

Installation Notes: Terms may be used in the body of the instructions that you may not be familiar with, if you have any questions feel free to contact us at the number below, or email techhelp@metalcloak.com

QUESTIONS: Any questions or comments about the instructions? Call us at 916-631-8071 M-F 7:00 AM – 5:00 PM PST.

Section 2: Product Components

DC-0001 REV A

SHEET 1 OF 1

ITEM	PART NUMBER/DESCRIPTION	QTY.	BIN
1	FM-12132 TOPLOCK NUT, M12-1.75 X 12H STL C10 ZINC	2	C41
2	FS-09032 WASHER, 0.56ID X 1.38OD 0.11TH STL ZINC	2	B7
3	SS-1090 SWAY BAR LINK KIT, JK 12.25L	1	

THE INFORMATION CONTAINED ON THIS DRAWING IS THE EXCLUSIVE PROPERTY OF ARMORED WORKS, LLC. UNAUTHORIZED REPRODUCTION IS PROHIBITED.
DO NOT SCALE DRAWING



METAL CLOAK
 A DIVISION OF ARMORED WORKS, LLC

PART NUMBER	7015 SWAY BAR LINK KIT, 12.25 INCH JK
DESCRIPTION	

Section 3: Installation Instructions

Step 1: Prepare for Installation

- A. Use the two 18mm wrenches or socket to unbolt the lower bolt of the sway bar end link.
- B. Use the 19mm wrench to hold ball socket side on upper attaching point (Inside the rubber cover).
- C. Use the 18mm wrench for the back side of the sway bar to remove the nut.
- D. Remove the factory sway bars.




Note: *Keep all factory hardware.*

Section 3: Installation Instructions



Step 2: Assemble & Install



Important Note: MetalCloak recommends using red Loctite on each of the upper spindles of the sway bar end links.

- E. Using the factory hardware install the washer and the bottom of the MetalCloak extended sway bar links.
- F. Using the factory hardware install the top of the MetalCloak extended sway bar links.
- G. Torque upper and lower bolts to 75lbs.